

ON A 1/4 INCH THICK PIECE OF WOOD—THAT MEASURES 5"X51/2"—DRAW 1/2" SQUARES. NEXT DRAW IN THE BODY AND ARMS AS SHOWN IN THE TOP SKETCH. BE SURE THE GRAIN OF THE WOOD RUNS AS SHOWN. SAW OUT THE-PARTS WITH A FRET SAW, AND DRILL THE HOLES MARKED +.

SANDPAPER THE PARTS SAWN OUT TO GIVE A SMOOTH FINISH.

TWO ROUND STICKS ARE REQUIRED FOR THE UPRIGHTS. THESE ARE 18" LONG. DRILL A HOLE 1/2" FROM THE TOP OF EACH OF THESE STICKS. ON ONE — SCREW A SCREW EYE 8" DOWN FROM THE TOP.

PINS OR NAILS ARE USED TO FASTEN THE ARMS AND LEGS TO THE GODY AND UPRIGHTS.

(SEE SKETCH AT RIGHT)

BEFORE FASTENING THE HANDS TO THE UPRIGHT—INSERT THIS STICK INTO THE SCREWEYE.

HE TAIL IS A PIECE OF STRING-GLUED INTO A HOLE IN THE BODY.

